

## 0111

## BNA\* Brass Olive



Brass

Scan for more  
dimensions

| ØD | References |
|----|------------|
| 4  | 0111 04 00 |
| 5  | 0111 05 00 |
| 6  | 0111 06 00 |
| 8  | 0111 08 00 |
| 10 | 0111 10 00 |
| 12 | 0111 12 00 |
| 14 | 0111 14 00 |
| 15 | 0111 15 00 |
| 16 | 0111 16 00 |

\*BNA (Bureau de Normalisation de l'Automobile) is the French Automobile Standardization Office.

## 0124

## Brass Olive



Brass

Scan for more  
dimensions

| ØD | References |
|----|------------|
| 4  | 0124 04 00 |
| 5  | 0124 05 00 |
| 6  | 0124 06 00 |
| 8  | 0124 08 00 |
| 10 | 0124 10 00 |
| 12 | 0124 12 00 |
| 14 | 0124 14 00 |
| 15 | 0124 15 00 |
| 16 | 0124 16 00 |
| 18 | 0124 18 00 |
| 20 | 0124 20 00 |
| 22 | 0124 22 00 |
| 25 | 0124 25 00 |
| 28 | 0124 28 00 |

## 0124..40

## Steel Olive



Zinc-plated steel

Scan for more  
dimensions

| ØD | References    |
|----|---------------|
| 4  | 0124 04 00 40 |
| 5  | 0124 05 00 40 |
| 6  | 0124 06 00 40 |
| 8  | 0124 08 00 40 |
| 10 | 0124 10 00 40 |
| 12 | 0124 12 00 40 |
| 14 | 0124 14 00 40 |
| 15 | 0124 15 00 40 |
| 16 | 0124 16 00 40 |
| 18 | 0124 18 00 40 |
| 20 | 0124 20 00 40 |
| 22 | 0124 22 00 40 |
| 25 | 0124 25 00 40 |

## 0110

## Brass Nut



Brass

Scan for more  
dimensions

| ØD | C       | References |
|----|---------|------------|
| 4  | M8x1    | 0110 04 00 |
| 5  | M10x1   | 0110 05 00 |
| 6  | M10x1   | 0110 06 00 |
| 8  | M12x1   | 0110 08 00 |
| 10 | M16x1.5 | 0110 10 00 |
| 12 | M18x1.5 | 0110 12 00 |
| 14 | M20x1.5 | 0110 14 00 |
| 15 | M20x1.5 | 0110 15 00 |
| 16 | M22x1.5 | 0110 16 00 |
| 18 | M24x1.5 | 0110 18 00 |
| 20 | M27x1.5 | 0110 20 00 |
| 22 | M30x1.5 | 0110 22 00 |
| 25 | M33x1.5 | 0110 25 00 |
| 28 | M36x1.5 | 0110 28 00 |

## 0110..40

## Steel Nut



Zinc-plated steel

Scan for more  
dimensions

| ØD | C       | References    |
|----|---------|---------------|
| 4  | M8x1    | 0110 04 00 40 |
| 6  | M10x1   | 0110 06 00 40 |
| 8  | M12x1   | 0110 08 00 40 |
| 10 | M16x1.5 | 0110 10 00 40 |
| 12 | M18x1.5 | 0110 12 00 40 |
| 16 | M22x1.5 | 0110 16 00 40 |
| 18 | M24x1.5 | 0110 18 00 40 |

## 0110..60

## Brass Long Nut



Brass

Scan for more  
dimensions

| ØD | C       | References    |
|----|---------|---------------|
| 4  | M8x1    | 0110 04 00 60 |
| 6  | M10x1   | 0110 06 00 60 |
| 8  | M12x1   | 0110 08 00 60 |
| 10 | M16x1.5 | 0110 10 00 60 |
| 12 | M18x1.5 | 0110 12 00 60 |