

How to order

Part nos. basic units

Size	Part no.	Max. rotation	Type	Shaft
10	6V5100010F-275	275°	Single	Not Through Rod
	6V5100010F-095	95°	Double	
11	6V5200010F-275	275°	Single	
	6V5200010F-095	95°	Double	
22	6V1300030F-275	280°	Single	Through Rod
	6V1300030F-100	100°	Double	
33	6V2400030F-275	280°	Single	
	6V2400030F-100	100°	Double	

Part nos. basic units

Size	Part no.	Max. rotation	Type	Options
22	6V1357630F-220	220°	Single	Angle adjustment kit
	6V1357730F-100	100°	Double	
	6V1357635F-220	220°	Single	As above + PNP Sensors + plug
	6V1357735F-100	100°	Double	
	6V1357636F-220	220°	Single	As above + NPN Sensors + plug
	6V1357736F-100	100°	Double	
33	6V2457630F-220	220°	Single	Angle adjustment kit
	6V2457730F-100	100°	Double	
	6V2457635F-220	220°	Single	As above + PNP Sensor + plug
	6V2457735F-100	100°	Double	
	6V2457636F-220	220°	Single	As above + NPN Sensor + plug
	6V2457736F-100	100°	Double	

Part nos. angle adjustment and sensor kits

Size	Part no.	Options
22	6V03570	Angle adjustment kit
	6V03575	Angle adjustment kit with sensors PNP
	6V03576	Angle adjustment kit with sensors NPN
33	6V04570	Angle adjustment kit
	6V04575	Angle adjustment kit with sensors PNP
	6V04576	Angle adjustment kit with sensors NPN